

FIG. 1

/default-fonts		
	/draft	
		/style
		/size
	/letter-quality	
		/style
		/size
/interface		
	/serial	
		/baud-rate
		/parity
		...
	/parallel	
		...
/formats		
	/JCL	
		...
	/PostScript	
		...
...		

FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7A




FIG. 7D




FIG. 7B




FIG. 7C




FIG. 8


```

<?xml version="1.0"?>
<!DOCTYPE WML SYSTEM "wml.dtd">
<WML>
  <TEMPLATE>
    <DO TYPE="HELP" LABEL="help"> <GO URL="#help"/> </DO>
  </TEMPLATE>
  <CARD NAME="General settings" NEWCONTEXT="TRUE">
    <BR ALIGN="CENTER"/>
    Welcome to
    <BR ALIGN="CENTER"/>
    <BIG><B>SONY CD-Player 990X</B></BIG>
    <BR/> <BR/> <BR/>
    Please select the function you want to configure:<BR/>
    <A TITLE="set/edit CD labels">CD labels<GO
      URL="#CD_names"/></A>
    <BR/>
    <A TITLE="select play mode">Play mode<GO
      URL="#play_mode"/></A>
  </CARD>
  <CARD NAME="CD_names">
    <BIG><B>CD names:</B></BIG>
    <BR/>
    Enter a name for the currently inserted CD:
    <BR/>
    <INPUT TYPE="TEXT" KEY="CD_NAME" FORMAT="MMMMMM"
      EMPTYOK="TRUE"/>
    <DO TYPE="ACCEPT" LABEL="ok">
      <GO
URL="bluetooth://sony_cdp_990/cd_titles/add;$(CD_NAME)"/>
    </DO>
  </CARD>
  <CARD NAME="play_mode">
    <BIG><B>Play-modes:</B></BIG>
    <BR/>
    Select one of the following play modes:
    <BR/>
    <SELECT TITLE="play-modes:" KEY="PLAYMODE"
      DEFAULT="Normal">
      <OPTION VALUE="Normal" TITLE="Normal"/>
      <OPTION VALUE="Random" TITLE="Random"/>
      <OPTION VALUE="Shuffle" TITLE="Shuffle"/>
      <OPTION VALUE="UserDef" TITLE="User-Defined"/>
    </SELECT>
    <DO TYPE="ACCEPT" LABEL="ok">
      <GO
URL="bluetooth://sony_cdp_990/playmode/select;$(PLAYMODE)"/>
    </DO>
  </CARD>
  <CARD NAME="help">
    Some help text here...
  </CARD>
</WML>

```

FIG. 10